



Flat hood installed onto wall/ceiling/soffit type brackets

Top picture is exploded view of bracket with bolts and nuts and hood with end cap and screws.

Second picture is side elevation view on how the hood is attached to the brackets with bolts and nuts provided. First fix brackets to wall with correct fixing screw type for the application. If wall surface is siding, must install 12" high pressure treated wood to obtain a flat surface. If roof mount, the bracket shown will mount to the triangular adjustable angle roof mount bracket (provided). All brackets must be properly level with each other and protrude the same distance from the wall. Slide head of bolts into grooves of the hood and move them to line up with holes in top of brackets. Attach nuts from underneath. Then install the awning square bar of the awning into the brackets and put in bolt and nuts provided to retain awning into the brackets.